



15301930
Edition 1
March 2009

Combination Assembly

2000 Series

Parts Information



Save These Instructions


airpumping.co.uk

of 2009

Unit 16, Upminster Trading Park, Warley St., Upminster, Essex, RM14 3PL, ENG, UK

IR *Ingersoll Rand*

Combination Assembly 2000 Series C383X1-XXX Exploded Diagram



(Dwg. 15318694)

Combination Assembly 2000 Series C383X1-XXX Parts List

Item	Part Description	Material	Part Number
1	Filter (See Part List 15301898)	---	F353XX-XXX
2	Regulator (See Part List 15301906)	---	R373X1-XXX
3	Lubricator (See Part List 15301914)	---	L363X1-XXX
*	Piggyback (See Part List 15301922)	---	P393XX-XXX
4	Pin	Stainless Steel	104401
5	Spacer Housing	Aluminum	
6	T-Bracket	Aluminum	
7	Bolt	Steel	
8	Spacer Cover	Aluminum	
9	Spacer O-Ring	Nitrile	
10	Spacer	Nylon	

* Not illustrated.

Parts and Maintenance

When the life of the product has expired, it is recommended that the product be disassembled, degreased and parts be separated by material so that they can be recycled.

Product repair and maintenance should only be carried out by an authorized Service Center.

Refer all communications to the nearest **Ingersoll Rand** Office or Distributor.

Related Documentation

For additional information refer to:

Safety Information Manual 15301765.

Product Information Manual 15301773.

Maintenance Information Manual 15301781.

Manuals can be downloaded from fluids.ingersollrand.com.

